

# Configuration by the Web Page

## RemoteCOM (C20 - C25)

This page presents capabilities of the Ethernet Converters configuration. First of all, make sure that converter is connected to power supply and to the LAN using a patch cord. If the device has no static IP set up, it will be necessary to obtain its IP address in the local network. User interface is mostly similar for all converters but some subpages might be different for several models depending on amount of interfaces. In order to avoid issues, click on a “Help” button in the top right corner on every page.

## Login

To access the web page open the browser, type device’s IP address of the converter (default is **192.168.100.100**). Then log in using user’s personal credentials. If it is a first configuration or the converter had a factory reset, use default login details (login: **admin**, password: **admin123**).

[0ebd9613-722b-4a01-8258-91252cc88f74.png](#)

The configuration is available only if devices are connected to the same Local Area Network as the computer used for it.

## Status page

After a successful login, there should be an insight to important information such as: port status, service and ports which are in use and other details about the connection.

[621a9445-3b44-42ec-b18b-2dd9f1ff95ef.png](#)

## Changing username or password

After clicking “Edit User” under the user icon, it is possible to change the username or the password.

60a6ddcb-65d2-48f6-a471-9eaebc1f75bf.png

08cea4a8-e1e1-4241-a0ea-bf987363d2b7.png

If login details were forgotten, it would be necessary to do a factory reset via a USB/UART converter and a serial console.

## Ports page

This page allows to configure the device’s ports. There is a toggle switch next to the “Port” label by which it is possible to turn ON/OFF any particular ports.

99bb0679-5937-4fb6-b6f5-59e8d0b89d74.png

762f162a-1c33-4674-8f6f-827edb003235.png

Item		Description
Service	RemoteCOM	The RemoteCOM option lets to attach the port to a computer running the <a href="#">Redisage Configurator</a> as if it would be physically present in the computer.
	TCP Socket	TCP/UDP Socket exposes this port as a regular network socket - connect to this socket with own software and write/read data to send/receive data over the serial port without any additional software or serial port handling.
	UDP Socket	
Port		The service number - the device has an “IP Address” by which it is identified and a couple of services running on it. It's required to tell the device which service should be in use by entering this device's IP address and the port number in the RemoteCOM client or user’s software.
Connection Timeout [s]		The time specifying how often (every how many seconds) the "keep alive" packet will be sent to check if the client is still connected. Value 0 means that the connection is kept permanently without any timeout.

Item	Description
Inactivity Time [ms]	The maximum allowed time in milliseconds during which there is no data transfer. When connection is inactive for the time longer or equal to the entered value, then it will be closed. Value 0 means there is no measure of the inactivity time at all.
Encryption	Determine how the data is protected 'in flight' over a network. It is available only with the RemoteCOM service. Once enabled, it is necessary to set the password.
Password	Protect the communication between the device and various clients - keep it secret! Same settings have to appear in clients - without the correct passwords, a client will not be able to connect at all.
Termination	Enable/disable termination on the RS line.
Baud Rate	Determine the port's transmission speed over the data channel.
Data Bits	Determine the number of data bits in the port's message frame.
Parity	Enable/disable parity check in the port's message frame.
Stop Bits	Determine the number of stop bits in the port's message frame.
Notes	These notes are for information only - feel free to write down anything related to this port (device it connects to, etc.). They're also shown in the Configurator during the device discovery - in the other words, they're public.

Changing port's service closes all sockets connected to the ports.

In the UDP mode, port number 15051 is reserved for UDP broadcast service.

## Network page

In this section, network settings can be changed according to target LAN parameters.

8386aa9b-6add-432d-945d-303e590ed269.png

98a9fcdf-9549-4d9a-9e04-ef90021cfaff.png

Item	Description
Configuration Method	Enable/disable the DHCP server. If the DHCP server is disabled, the IP address of the device has to be set manually.
IP Address	IP address of the device.
Netmask	Netmask associated with the IP address.
Gateway	Gateway address currently used by the device.
MAC Settings	Allow setting the default MAC address or typing it manually.
MAC Address	Allow changing the physical address of the device.

e3574681-36ef-4fdb-8979-97046c2c7d5d.png

Item	Description
HTTP Port	Determine the port of the control panel.
Telnet Port	Allow connection with the device via Telnet.
Broadcasts	Notify RemoteCOM clients in the same network about this device's existence. With this enabled, the Configurator will automatically set most of the settings correctly after picking the correct port.
Hostname	Label that is assigned to the device.
DNS Address 1 (Primary)	Primary Domain Name System used by the device.
DNS Address 2	Domain Name System used by the device.

It is possible to obtain a dynamic IP address. Just switch configuration method from static IP to DHCP (automatic). This process may cause some issues with identifying converters in LAN unless there is an access to the device which is responsible for allocating IP addresses.

Keep in mind that in case of changed IP address user needs to type a new IP in the address bar and log in again.

## Device page

On the device page there are tools used to a firmware update, a factory reset and a device reboot.

[744e0c74-d7cf-43f3-a024-fa06e1bd9fc2.png](#)

Item	Description
Firmware Update	Update firmware.
Factory Reset	Restore default ports settings and default network configuration.
Reboot	Reboot the device.

## Firmware update

The device firmware update must not be interrupted. Update the device only if experiencing issues, being instructed to do so by our support or requiring the latest features/bugfixes. Failure during the update may 'brick' the device and make it unusable.

[71859a06-2f70-4920-be81-0d60bb5e451e.png](#)

Use the **wire-city-esp32.fir** file for a firmware update.

## Factory reset

To restore default settings, press the "Factory Reset" button. After that, user will be asked to type "RESET". Then it will take a few seconds to reload the web page and restart the device.

[c9d4ee5e-9727-4033-9a9f-12538328efb2.png](#)

## Info page

This page contains basic information about the device.

[1a9460c1-8525-4837-9f71-c1b91c86eece.png](#)

Revision #9

Created 25 March 2024 15:17:51

Updated 9 May 2024 07:24:04